


Sony Color Video Camera **CCD-Z8E**

Stecker (draufsicht)



- 1 – vcc
- 2 – gnd_(pwr)
- 3 – gnd_(audio)
- 4 – audio
- 5 – video
- 6 – nc
- 7 – nc
- 8 – gnd_(video)

Anschluss Kamera

